

ITALPUNTE

RICAMBI PER MARTELLI DEMOLITORI IDRAULICI
DEMOTER SERIE "S"

S 85

2015

ITALPUNTE Srl

10072 Caselle (Torino) - ITALIA

Tel. +39 011/9914190

Fax +39 011/9914476

italpunte@italpunte.com

www.italpunte.com

ITALPUNTE		DEMOTER S 85	
ITEM	CODE	DESCRIPTION	Q.TY
1	DM85S-001	Accumulatore <i>Accumulator</i>	1
2	DM85S-002	Cilindro <i>Cylinder</i>	1
3	DM85S-003	Boccola accumulatore <i>Accumulator bushing</i>	1
4	DM85S-004	Pistone <i>Piston</i>	1
5	DM85S-005	Corpo martello <i>Hammer body</i>	1
6	DM85S-006	Boccola fermautensile <i>Lower bushing</i>	1
8	DM85S-008	Tampone Superiore <i>Top stopper</i>	1
9	DM85S-009	Tampone Inferiore <i>Lower stopper</i>	1
10	DM85S-010	Carcassa Silenziata <i>Silenced case</i>	1
11	DM85S-011	Spina cilindrica fermautensile <i>Tool retainer pin</i>	1
13	DM85S-013	Piastra superiore <i>Upper plate</i>	1
14	DM85S-014	Sella <i>Saddle</i>	1
15	DM85S-015	Perno sella <i>Saddle pin</i>	2
16	DM85S-016	Targhetta CE <i>CE plate</i>	1
17	DM85S-017	Kit perni e boccole <i>Pin and bushing kit</i>	1
18	DM85S-018	Corpo Distributore <i>Distributor box</i>	1
19	DM85S-019	Ghiera distributore <i>Distributor ring nut</i>	1
20	DM85S-020	Tappo Superiore <i>Upper plug</i>	1
21	DM85S-021	Tappo inferiore <i>Lower plug</i>	1
22	DM85S-022	Pistoncino distributore <i>Distributor piston</i>	1
24	DM85S-024	Coperchio in lexan <i>Lexan cover</i>	1
26	DM85S-026	Adesivo DEMOTER <i>Label DEMOTER</i>	2
27	DM85S-027	Adesivo carica azoto <i>Label N2 gas charge</i>	1
28	DM85S-028	Adesivo attenzione <i>Label Use-Caution</i>	1
29	DM85S-029	Nottolino ferma spina <i>Tool retainer pin</i>	1
30	DM85S-030	Coperchio accumulatore <i>Accumulator cap</i>	1
32	DM85S-032	Adesivo modello S 85 <i>Model label S 85</i>	2
33	TVA-001	Tappo esagonale valvola azoto <i>N2 valve plug</i>	1
N01	DM85S-033	Brugola tappo superiore <i>Upper plug allen screw</i>	4

ITEM	CODE	DESCRIPTION	Q.TY
N02	DM85S-034	O.R. tappo superiore distributore <i>O-Ring upper plug distributor</i>	1
N03	DM85S-035	B.K. tappo superiore distributore <i>B.K. Upper plug distributor</i>	2
N04	DM85S-036	O.R. tappo superiore distributore <i>O-Ring Upper plug distributor</i>	1
N05	DM85S-037	Brugola corpo distributore <i>Distributor body allen screw</i>	6
N06	DM85S-038	B.K. tappo inferiore distributore <i>B.K. Distributor lower plug</i>	1
N07	DM85S-039	O.R. tappo inferiore distributore <i>O-Ring distributor lower plug</i>	1
N08	DM85S-040	O.R. travaso facciata inferiore <i>O-Ring lower face distributor</i>	1
N09	DM85S-041	O.R. travaso distributore <i>O-Ring racking distributor</i>	2
N10	DM85S-042	O.R. travaso centrale distributore <i>O-Ring central racking distributor</i>	1
N11	DM85S-043	Rondella distributore <i>Washer distributor</i>	3
N12	DM85S-044	Tappo distributore <i>Distributor plug</i>	3
N15	DM85S-047	Spina centraggio distributore <i>Distributor pin</i>	2
N16	DM85S-048	Brugola Accumulatore + Tappo inferiore distributore <i>Allen screw Accumulator + Upper plug distributor</i>	13
N17	DM85S-049	Clip arresto perni sella <i>Clips for locking pin of saddle</i>	4
N18	DM85S-050	Valvola carica azoto <i>N2 nitrogen valve</i>	1
N19	DM85S-051	Brugola accumulatore <i>Allen screw accumulator</i>	1
N20	DM85S-052	O.R. accumulatore <i>O-Ring accumulator</i>	1
N21	DM85S-053	Spina accumulatore <i>Accumulator pin</i>	4
N22	DM85S-054	Guarnizione ID <i>ID seal</i>	3
N23	DM85S-055	O.R. cilindro e boccia <i>O-Ring cylinder & bushing</i>	5
N24	DM85S-056	B.K. Cilindro e boccia <i>B.K. Seal cylinder & bushing</i>	7
N25	DM85S-057	Guarnizione OMEGAT <i>Omegat seal</i>	1
N26	DM85S-058	Raschiatore cilindro e punta <i>Cylinder and tool scraper</i>	1
N27	DM85S-059	Spina elastica nottolino <i>Nut lock elastic pin</i>	1
N28	DM85S-060	Grano foro boccia <i>Bushing grab screw</i>	1
N29	DM85S-045	O.R. tappo esagonale valvola azoto <i>O-Ring N2 nitrogen valve plug</i>	1
N30	DM85S-061	Ingrassatore <i>Grease nipple</i>	1
N31	DM85S-062	Dado autobloccante sella <i>Saddle selflock nut</i>	6

ITALPUNTE		DEMOTER S 85	
ITEM	CODE	DESCRIPTION	Q.TY
N32	DM85S-063	Bullone sella <i>Saddle bolt</i>	6
N33	DM85S-064	Vite parker coperchio <i>Cover parker screw</i>	4
N34	DM85S-065	Rivetto targhetta CE <i>CE plate rivet</i>	4
N36	DM85S-066	Molla nottolino <i>Nut lock spring</i>	1
N37	DM85S-067	Brugola coperchio accumulatore <i>Allew screw accumulator cover</i>	10
N38	DM85S-068	O.R. coperchio accumulatore <i>O-Ring accumulator cover</i>	1
N39		Raschiatore punta <i>Tool scraper</i>	1
N40		Vite tappo accumulatore <i>Screw accumulator plug</i>	1
N41		ROSETTA ACCUMULATORE <i>Washer accumulator plug</i>	1
N43		Tappo raccordo 90° IN-OUT olio <i>IN-OUT oil nipple 90° plug</i>	2
N44	DM85S-046	Raccordo 90° IN-OUT olio <i>IN-OUT oil nipple 90°</i>	2
N48		Rondella raccordo 90° <i>Nipple 90° washer</i>	2
	DM85S-069	"A" KIT GUARNIZIONI MARTELLO S 85 <i>"A" Seal kit for S 85 hammer</i>	1
	DM85S-070	"B" KIT TAPPO VALVOLA AZOTO <i>"B" N2 Nitrogen valve kit</i>	1
N49		Etichetta PESO <i>Weight sticker</i>	1
N50		Etichetta RUMORE <i>Noise sticker</i>	1